

Schneider Automation BootP Lite Ethernet IP Address Download Utility for Schneider Automation Ethernet Products Instruction Sheet

Part No. 31002087 Revision 00A



CAUTION

Be sure to verify the MAC address of the target device before invoking this program. If you do not enter the correct parameters of the target controller, it will come up running in its old configuration. An incorrect MAC address may cause an unwanted change to another device and cause unexpected results.



Note: Where possible, we recommend that you install and operate BootP Lite and the target device on an isolated network. Also, verify that the target device has been correctly modified. This will prevent any unexpected results from affecting your network.

BootP Lite Software Description

BootP Lite is a Windows-based software utility for downloading an Ethernet IP address, default router and subnet mask to Schneider Ethernet Products.

When used with the ENT Communication Adapter, the utility permanently changes the IP address in the adapter's flash memory.

When used with an M1 Ethernet Processor, the utility changes the IP address, default router and subnet mask of the processor. Optionally, it may cause the processor to enter Stopped mode on completion of power up. This is useful when inappropriate outbound network traffic might result if the processor immediately transitioned into Run mode after power up.

Continued on next page

**BootP Lite
Software
Description,
continued**

When used with a Quantum NOE communications module, the utility changes the IP address, default router, and the subnet mask of the processor. Optionally, it may cause the processor to enter "stopped" mode on completion of power up. This is useful when inappropriate outbound network traffic could result if the processor immediately transitioned into Run mode after power up.

When used with a Quantum 140 NOE 771 x0, the utility changes the IP address, default router, and the subnet mask of the NOE. These settings are volatile and are only intended to allow the user to connect to the NOE over Ethernet using a programming panel to configure the CPU.



Note: The BOOTP Lite utility will not configure and NOE when run on a PC, which already has a BOOTP server running. Either use BOOTP Server on the PC or use the BOOTP Lite utility on another PC

See the Responses to BootP Lite Commands section found later in this document.

**BootP Lite
Software
Installation**

Ensure that the following has been done.

- Copy "Bootplt.exe" to the directory from which you wish to execute the program.
 - Your computer must be running Windows 95, Windows 98, or Windows NT.
 - Your computer must provide a network connection, via an Ethernet Communications card, to the Ethernet network on which the target processor, or adapter is located.
-

**Invoking BootP
Lite**

The utility is invoked from the DOS command line or the MS-DOS Prompt under Windows 95 or the Command Prompt under Windows NT.

You should be physically near the target device to power cycle it and to verify correct operation.

Step	Action
1	Invoke Bootp Lite is invoked from the command line (see the details in the following table).
2	Power cycle the target when prompted.
3	Diagnostic or error messages will be displayed as the process proceeds.
4	Check the LED blink pattern of the target hardware to confirm the success of the operation. Refer to section called "Responses to BootP Lite Commands".

**BootP Lite
Commands**

The following tables provide descriptions of the BootP Lite commands.

Command Name	bootplt
Description	This command invokes the utility and causes it to display the following information about itself.
Format	"bootplt" <enter>
Actions	No bootp messages are sent.
Output	<p>The following message is displayed.</p> <pre> Schneider Automation Ethernet Adapter IP address change utility Win32 version for Windows 95/98 and NT V01.01 10/01/99 required required optional optional usage: bootplt mac_address ip_address ip_router ip_mask eg bootplt 000054000001 198.202.138.77 192.202.138.254 255.255.255.0 This program will assign an IP address Ethernet device. Remember to power cycle the Ethernet module WHILE the BOOTP messages are being sent out . </pre>
Command Name	bootplt ip_addr target_mac_addr
Description	This command invokes the utility and sends the new network address (ip_addr) to the processor or adapter whose MAC address is given by target_mac_addr.
Format	<p>bootplt target_mac_addr ip_addr where:</p> <p><i>Bootplt</i> is the name of the utility.</p> <p><i>target_mac_addr</i> is the existing MAC address of the target processor or adapter. It must be in hexadecimal format. This information is located on the end panel of both the ENT and M1 Ethernet module, and on the front panel of the NOE module.</p> <p><i>ip_addr</i> is the new TCP/IP network address for the target processor or adapter (for example 198.202.138.77). It must be in dotted decimal format.</p> <p>Example: bootplt 000054000001 198.202.138.77</p>

Continued on next page

**BootP Lite
Commands,
continued**

Command Name	bootplt target_mac_addr ip_addr default_router subnet_mask
Description	This command invokes the utility and sends the new network address (<i>ip_addr</i>) to the processor or adapter whose MAC address is given by <i>target_mac_addr</i> . Additionally, it updates the target's default router and subnet mask. Note that while the default router address and subnet mask are optional, if one is specified, both must be specified, in the order indicated here.
Format	<p>bootplt target_mac_addr ip_addr default_router subnet_mask, where:</p> <p><i>Bootplt</i> is the name of the utility.</p> <p><i>target_mac_addr</i> is the existing MAC address of the target processor or adapter. It must be in hexadecimal format. This information is located on the end panel of both the ENT and M1 Ethernet module, and on the front panel of the NOE module.</p> <p><i>ip_addr</i> is the new TCP/IP network address for the target processor or adapter (for example 198.202.138.77). It must be in dotted decimal format.</p> <p>Example: bootplt 000054000001 198.202.138.77</p> <p><i>default_router</i> is the IP address of the default router to be used by the target (for example, 198.101.100.661). It must be in dotted decimal format.</p> <p><i>subnet_mask</i> is the IP address of the subnet mask to be used by the target (for example, 198.101.000.000). It must be in dotted decimal format.</p> <p>Example: "bootplt 000054000001 198.202.138.77" 198.222.100.101 200.100.000.000"</p>

**Responses to
BootP Lite
Commands**

When used with the ENT communications adapter

1. The new IP address is permanently stored in the adapter's flash memory.
2. To confirm that the download operation has been successful, check the condition of the following LED:
Run LED is ON

When used with the M1 Ethernet Processor in "passive bootp" mode

If the target has been configured for "passive bootp" mode via the "Use IP" option in the Concept programming panel, on power up:

1. The processor will enter Stopped mode after power up is completed.
2. The new IP address may be used to communicate with the controller.
3. To confirm that the download operation has been successful, check the following LED's:
LAN Status LED: ON
Run LED: OFF

The downloaded IP address may be used to communicate with the processor. This new IP address, default router and subnet mask are volatile. You may use a programming panel (such as Concept V2.2 or greater) to permanently store this information.

When used with the M1 Ethernet Processor in "active bootp" mode

If the target has been configured for "active bootp" mode via the "Use BootP" option in the Concept programming panel, on power up:

1. The processor will transmit BootP requests until a BootP response is received.
2. The processor will Start on completion of power up, if it has been programmed to do so.
3. To confirm that the download operation has been successful, check the following LEDs:
LAN Status LED: ON
Run LED ON (if the processor has been programmed to start, otherwise OFF)

The downloaded IP address may be used to communicate with the processor. This new IP address, default router and subnet mask are volatile. You may use a programming panel (such as Concept V2.2 or greater) to permanently store this information.

Continued on next page

**Responses to
BootP Lite
Commands,
continued**

When used with an un-configured M1 Ethernet Processor

If the target is un-configured, ie, contains no program, or contains no configuration extensions (this is the default as shipped from the factory), on power up:

1. The processor will enter Stopped mode after power up is completed;
2. The new IP address may be used to communicate with the controller
3. To confirm that the download operation has been successful, check the following LEDs:
LAN Status LED: ON
Run LED: OFF

The downloaded IP address may be used to communicate with the processor. This new IP address, default router and subnet mask are volatile. You may use a programming panel (such as Concept V2.2 or greater) to permanently store this information.

When used with a Quantum 100 megabit NOE module

1. The downloaded IP address may be used to communicate with the NOE.
2. To confirm that the download operation has been successful, check the following LEDs:
Run LED: ON

The new IP address, default router and subnet mask are volatile. You may use a programming panel (such as Concept V2.2 or greater) to permanently store this information.

**Progress
Messages**

During successful operation, the following sequence of messages will appear on your display.

```
Using MAC address nnnnnnnnnnnn and IP address nnn.nnn.nnn.nnn
Did you PING to prove that this IP address does not already
exist?
```

```
Enter Y to continue:
```

```
(If you answer 'Y', you will see the following)
```

```
Program aborted
```

```
(If you answer 'Y', you will see the following)
```

```
Continue BOOTP initialization
```

```
You should power cycle the Ethernet module now
```

```
Sending BootP message 1 of 10
Sending BootP message 2 of 10
Sending BootP message 3 of 10
Sending BootP message 4 of 10
Sending BootP message 5 of 10
Sending BootP message 7 of 10
Sending BootP message 8 of 10
Sending BootP message 9 of 10
Sending BootP message 10 of 10
```

```
BootP broadcast sequence complete
```

Continued on next page

**Progress
Messages,
continued**

(You will see one of the following messages, depending on the response from the target device)

```
Found node type = n: NOE2X1 Network Option Module
                        or
ENT Communication Adapter
                        or
M1 Ethernet PLC
                        or
NOE771-00 Network Option Module
                        or
ETY
                        or
CIP
                        or
NOE771-10 Network Option Module
                        or
CRA771-00 Network Option Module
                        or
UNKNOWN
```

(If the target is not an ENT adapter, you will see the following:)

```
Target node is not ENT type so this utility cannot save
current IPaddress to flashram. You must connect to target
node using the proper programming tool to save current IP
address to flashram, if appropriate.
```

(If the target node is an ENT adapter, you will see the following:)

```
Do you wish to save this IP address to the ENT flashram?
Enter Y to continue:
```

Continued on next page

**Progress
Messages,
continued**

If you do not enter 'Y', you will see the following:

```
Program aborted
```

(If you do enter 'Y', you will see the following:)

```
Continue save IP to ENT flashram
```

```
Send of 'record IP address' request message complete
```

(If your target is an ENT adapter, you will see one of the following messages, depending on the version of the firmware in the adapter.)

```
Second connect failed. The ENT module has erased the previous  
IP address contained in flashram and is now searching for IP  
address. You must now invoke this procedure a second time to  
complete the save to flashram process.
```

OR

```
Second connect succeeded. The ENT module should now have the  
desired IP address saved to flashram. To prove this, it is  
best to power cycle the ENT one more time. Then, after the 20  
second powerup initialization period has elapsed, you should  
be able to PING the unit, and it should retain this ability  
after all subsequent power failures.
```

Error Messages

Should an operational failure occur one or more of the following error messages will be displayed.

Schneider Automation Ethernet Adapter IP address change utility Win32 version for Windows 95/98 and NT V01.00 7/01/99

```
usage: bootplt required required optional optional
          mac_address ip_addr ip_router ip_mask
```

```
eg bootplt 000054000001 198.202.138.77 192.202.138.254
255.255.255.0
```

This program will assign an IP address Ethernet device. Remember to power cycle the Ethernet module WHILE the BOOTP messages are being sent out.

This message will appear under one or more of the following conditions:

1. The mandatory IP address or MAC address is missing or mis-formed.
2. Either the default router or subnet mask is missing or mis-formed (applies only when these optional parameters are specified).

For requirements on command line format, refer to the section on command line descriptions.

The IP addresses (ip_addr, default_router, subnet_mask) must be in dotted decimal notation, consisting of four decimal numbers from 0 to 255 separated by dots. The MAC address must be in hexadecimal format, consisting of 12 contiguous hex digits.

Bad IP address - all fields must be 0-255
Each number in the IP address must be in the range from 0 to 255.

Bad Default Gateway address - all fields must be 0-255
Each number in the gateway address must be in the range from 0 to 255.

Bad Sub Network mask - all fields must be 0-255
Each number in the sub network mask must be in the range from 0 to 255.

Continued on next page

Error Messages,
continued

Cannot initialize WinSock
The Windows communications socket cannot be initialized to send the message.
Check that WIN32 Winsock services and a network connection are available.

Bind returns nnn
Perhaps there is a BOOTP or DHCP server already be running
You are running this program on Windows 9X or Windows NT and are also running
a BootP server or a DHCP server on the same machine. Shut down the server.

Setsockopt returns nnn
Could not get authority to BROADCAST messages
The Windows communications socket could not broadcast the bootp message.
Under Windows NT or 9x, a system administrator may have banned user programs
from issuing broadcast messages. Check with your system administrator.

Sendto returns nnn
Unexpected problem sending UDP datagram to target
You may be experiencing network difficulty. Try PINGing the target to verify the
network connection.

Connect on port 502 returns nnn
Target IP address not found
Attempt to establish a MODBUS/TCP connection failed. The target device does not
appear to support MODBUS/TCP. Verify that the target is a MODBUS/TCP
compliant product

Send - error n
You were denied permission to send a message to the target requesting it's
statistics (including module ID). Check with your system administrator.

Continued on next page

Error Messages,
continued

Send() returned nnn
unexpected problem sending MODBUS message to target
You are experiencing a general network problem. Try PINGing the target.

No TCP response received
You may be experiencing a general network problem. Try PINGing the target.

Invalid network statistics response
Verify that the target you are addressing is a supported Schneider Automation Ethernet product.

Unexpected network statistics data
Found MAC address nnnnnnnnnnnn and IP address nnn.nnn.nnn.nnn
Connection to wrong Ethernet device is now aborted
Verify that the target you are addressing is a supported Schneider Automation Ethernet product.

Select returns nnn
Unexpected Winsock error occurred
You may be experiencing a general network problem. Try PINGing the target.

**System
Compatibility**

BootP Lite is designed to work properly with the following Modicon products.

Product	Model Number	Firmware Version
NOE 100 Megabit Communications Module	140 NOE 771 00	1.0 or greater
NOE Factory Cast Communications Module	140 NOE 211 10	1.0 or greater
	140 NOE 711 10	
M1 Ethernet Processor	171 CCC 960 20	1.0 or greater
M1 Ethernet Processor	171 CCC 980 20	1.0 or greater
ENT Communications Adapter	170 ENT 110 00	1.0 or greater

**System
Requirements:**

BootP Lite requires an IBM or compatible personal computer with an Ethernet network communications card, running a DOS session under one of the following operating systems:

- Windows 95
- Windows 98
- Windows NT

**Further
Information**

For complete information concerning the M1 Ethernet Processors and the ENT Communications Adapter, obtain copies of the *Momentum M1 Hardware Manual* (840 USE 101 00). For information on the 100 Mbit NOE Communications Module, obtain the *Quantum Ethernet 10/100 Megabit Ethernet Module User Guide* (840 USE 116 00).
